








Hoekstand/ Corner Booth

Kopstand/ Front Booth

Rijstand/ Row Booth



SYSTEEMBOUW | Paneelmaten  
SHELL-SCHEME | Panel dimensions



CONDITIONS

When fixing materials/ remainders have to be removed afterwards, the exhibitor will be charged for cleaning costs or the replacement value of the wall.

- 1) It is not allowed to drill, nail or staple into the wall panels
- 2) It is not allowed to write on the wall panels with ballpoint, pencil, etc.
- 3) Please do not use any kind of fixing material that causes any damage to the wall panels and the aluminium structure (for example glue).

All measurements are in millimeters

REGLEMENTEN

- 1) Het is niet toegestaan in de wanden te boren, te schroeven, te nieten en te spijkeren.
- 2) Het is tevens niet toegestaan om op de wanden te schrijven met ballpoint, stiften, potloden, e.d.
- 3) De wanden en de aluminium frames mogen niet beplakt worden met dubbelzijdig tape of andere bevestigingsmaterialen, indien deze bij verwijdering lijmresten achterlaten. Mocht dit laatste toch het geval zijn, dienen de lijmresten door u zelf verwijderd te worden.

Eventuele schoonmaakkosten, die naderhand door ons gemaakt moeten worden voor het verwijderen van posters, tape, lijmresten e.a., zullen bij u in rekening worden gebracht. Bij beschadigingen aan de wanden, zodanig dat deze niet meer herbruikbaar zijn, wordt de vervangingswaarde per wand in rekening gebracht.

Alle maatvoeringen zijn in millimeters